

Ironworker Welder Certification Program

of North America 1750 New York Avenue NW Washington DC, 20006 202-383-4814

## **IWCP Welder Certification Renewal Instructions**



Process: SMAW Joint: AWS B-U2a	F#: 4	Code:	AWS D1.1, D1.5
Spec. #: AWS A5.1, A5.5	Material: ASTM	A-36 me	ets M270/A709 Gr 36
Class # AWS E7018			
Type: ASTM A-36			
Thickness: 1"			
Thick Qual: 1/8" to U Backing: ASTM A-36			
Curr.: DC			Gas:
Pos.: 3G Up, 4G	Vert. Prog.: Vertical Up		Pol.: REV.
Membership #: 1239735			
BEARER OF THIS CA	FAN APPROVED AWS SI ARD MAY BE VERIFIED B IRKER NATIONAL WELD	YCALLI	NG OR WRITING THE
175	NEW YORK AVENUE, N WASHINGTON, D.C.		E 400
PHONE	(202) 383-4814 EMAIL: v		workers orr

ICWP Welder Certification must be maintained once a year by you completely filling out:

- Ironworker National Welding Certification Program Continuity Logbook pages provided by the Ironworkers Welder Certification Program when you received your welder certification card in the mail. It is a 3½" x 5½" orange colored logbook.
- The Orange Continuity Logbook pages must be filled out once every (6) six months twice a year. The
  (2) two log pages are <u>submitted once a year (30) thirty days before your expiration date indicated on</u> <u>the IWCP Welder Certification card.</u> No sooner than 90 days prior to expiration date.
- 3. The welder completely fills out the (2) log pages. The First Six Months log page and the Second Six Months log page. Each question must be answered.
- 4. **The First Six Months** dates of employment start from the month of effective date. Including the month of your effective date, count (6) six months.

*Example:* <u>Employed from: 8/2019 to 2/2020.</u> (Effective Date of card shown above.) Each question must be answered. **The welder does not sign the log page.** 

 The Second Six Months dates of employment start from the following month of last month written on the First Six Months log page. (3/2020)
 Example: Employed from: 3/2020 to 7/2020

Example: Employed from: 3/2020 to 7/2020.

<u>7/2020</u> (is 30 days before the expiration date 8/2020)

Each question must be answered. The welder does not sign the log page.

- 6. The Supervisor is the person that signs the log page at the bottom. Supervisor can be your foreman. A CWI or an Inspector can sign the log pages with their stamp included, no exceptions. When not working, the welder can go to the Local 580 ATF to get the CWI to sign after performing their welding abilities. The welder does not sign the log page.
- A photocopy of the IWCP Orange Continuity Logbook (2) Pages can be submitted by mail or email. Email is highly recommended. The contact information is provided on the back of the welder certification card. You can take a photo of the (2) log pages from your phone and attach the photo in the email to wcp@ironworkers.org NO FEE.

## Your responsibility is to confirm receipt of the form from IWCP in Washington DC.



## American Welding Society

8669 NW 36<sup>TH</sup> Street #130 Miami, Florida 33166-6445 800-443-9353 Ext.273

## **AWS Welder Certification Renewal Instructions**

A	AWS Imerican Welding Soc	iety*		CERTIFIED rs, Brazers an				7420		
	de		Your				AWS	Ame	rican Welding So	-
		C	ert # 110	)5036W		Robert			<b>CERTIFIED WELDER</b>	
	Certifi erification of the in	formation	partment of 1 IW 36th St., # on this card, i	verified by calling or wr the American Welding 130, Miami, FL 33166 ncluding the test date a www.aws.org/certificat	Society nd expiration		This Card	is the property	y of AWS and shall be returned on demand.	
	Certifi erification of the in	ication De 8669 M formation iting the AN	partment of t W 36th St., # on this card, i WS website at	the American Welding 130, Miami, FL 33166 ncluding the test date a	Society nd expiration		This Card	is the property	y of AWS and shall be returned on demand.	
	Certifi artification of the in se obtained by visi	ication De 8669 M formation iting the AN	partment of t W 36th St., # on this card, i WS website at	the American Welding 130, Miami, FL 33166 ncluding the test date a	Society nd expiration		This Card	is the property	Thickness, Backing	Expires
	Certifi erification of the in be obtained by visi Your I Test Date 3/30/2011	ication De 8669 M formation iting the AV Name Sup G	partment of f IW 36th St., # on this card, i WS website at Code D1.1	the American Welding 130, Miami, FL 33166 notuding the test date a www.aws.org/certifican Process(es) SMAW	Society nd expiration tion/cw_sear GAS N/A	Filler Metal E7018	Base Metal			Expires 4/9/2019
	Certifi erification of the in se obtained by visi Your I Test Date	ication De 8669 M formation ting the AV	partment of f IW 36th St., # on this card, i WS website at Code	the American Welding 130, Miami, FL 33166 ncluding the test date a www.aws.org/certificat	Society nd expiration tion/cw_sear GAS	Filler Metal	Base Metal	Pos	Thickness,Backing Thickness,Pipe;OD & Backing	

AWS Welder Certification must be maintained every (6) months by completely filling out:

- 1. *Maintenance of Welder Certification form* provided by AWS at least **30 days before the expiration date** indicated on the back of the certification card as shown in above illustration.
- 2. The Maintenance of Welder Certification form can be downloaded at the: www.aws.org/certification/cw/ web site.
- 3. The <u>Maintenance of Welder Certification form</u> is completed by the welder and <u>NOT</u> signed by the welder. Your employer / supervisor or ATF can sign the form.
- 4. The date of the process used must match the date of signature.
- 5. The photo copy or picture of the Maintenance of Welder Certification form can be mailed, or **emailed to**:<u>cw@aws.org</u> the information is on the form with a \$25 FEE by debit or credit card. **Email is recommended.**

Your responsibility is to confirm receipt of the maintenance form to AWS in Florida.